

Here are some helpful tips and images for attaching the gogo Kidz Travelmate to the Eddie Bauer High Back Booster

You will need the following components:

- Assembled Travelmate Plate
- Universal Strap, with Cleats attached by the O-rings
- 2 Thumbscrews.



- 1) Lay your car seat face down on the floor. Feed the Universal Strap through the space in the back of the car seat where the seat belt is normally fed. **Please note the position of the cleats on the strap should be on the inside grommet on the side with 2 holes and the 3<sup>rd</sup> grommet on the side with 4 holes. (second closest hole to the inside of the strap)**



- 2) Now lay the Travelmate down onto the seat, positioning the support tabs underneath the bottom of the ribs as shown. The Travelmate should be centered on the car seat.



- 3) Insert the two thumbscrews into the 2<sup>nd</sup> hole from the top of the 5 allotted holes running down each side of the Travelmate. Then simply screw the thumbscrews into the cleats and tighten fully.



- 4) You are now ready to use your Go-Go Babyz Travelmate!

