

Here are some helpful tips and images for attaching the gogo Kidz Travelmate to the Evenflo Triumph car seat

You will need the following components:

- Assembled Travelmate Plate
- Evenflo Triumph Strap with cleats and O-rings
- 2 Thumbscrews



- 1) Lay your car seat face down on the floor. Feed the Triumph Strap through the space in the back of the car seat where the seat belt is normally fed. **Please note the position of the cleats on the strap should be on the inside grommet on the side with 2 holes and the inside grommet on the side with 3 holes. (closest holes to the inside of the strap)**



*** It is also important to note that the car seat must be fully reclined ***

- 2) Now lay the Travelmate down onto the seat positioning the support tabs underneath the bottom of the cars seat as shown. Please note that the Support tabs will hook under the bottom of the seat as there are no “ribs” on the Triumph.



- 3) Insert the two thumbscrews into the 2nd hole from the Top of the 5 allotted holes running down each side of the Travelmate. Then simply screw the thumbscrews into the cleats and tighten fully. It may seem as though the Strap is short, but by tightening the thumbscrews the strap will reach sufficiently.



- 4) You are now ready to use your Go-Go Babyz Travelmate!

