

Here a few helpful tips and images to attach the
gogo Kidz Travelmate to the Sunshine Kids Radian car seats

You will need the following components:

- Assembled Travelmate Plate
- Universal Strap with Cleats attached by the O-rings
- 2 Thumbscrews

- 1) Lay your car seat face down on the floor. The Universal Strap should then be **fed through the space on the car seat where the seat belt would be fed through**. Note: the position of the cleats on the universal strap should be positioned on the **2nd grommet hole on one side of the cleat (shown in the photo below) and on the inner most grommet hole on the alternate side**.



- 2) The Travelmate should then be aligned with the bottom of the car seat. The two support Tabs of the Travelmate should rest under the lip of the bottom of the car seat, slightly inside the red tabs for the folding mechanism.



- 3) The next step is to insert the two Thumbscrews into the Travelmate Plate and screw them into the Cleats. The Thumbscrews should be inserted into the 2nd hole from the top.



- 4) Simply tighten the Thumbscrews and your Travelmate is ready for use.

