

## Here are some helpful tips and images for attaching the gogo Kidz Travelmate to the Alpha Omega Car Seat

You will need the following components:

- Assembled Travelmate Plate
- Universal Strap, with Cleats attached by the O-rings
- 2 Thumbscrews.



- 1) Start By laying your car seat face down on the floor. Feed the Universal Strap through the space in the back of the car seat where the seat belt is normally fed. **Please note the position of the cleats on the strap should be on the outside grommet on the side with 2 holes and the 3<sup>rd</sup> grommet on the side with 4 holes. (second closest hole to the inside of the strap)**



- 2) Now lay the Travelmate down onto the seat positioning the support tabs underneath the bottom of the ribs as shown. The Travelmate plate should be centered on the car seat.



- 3) Insert the two thumbscrews into the 2<sup>nd</sup> hole from the bottom of the 5 allotted holes running down each side of the Travelmate. Then simply screw the thumbscrews into the cleats and tighten fully.



- 4) You are now ready to use your Go-Go Babyz Travelmate!

