

Here a few helpful tips and images to attach the
gogo Kidz Travelmate to the Evenflo Titan car seat

You will need the following components:

- Assembled Travelmate Plate
- Universal Strap with Cleats attached by the O-rings
- 2 Thumbscrews

- 1) Lay your car seat face down on the floor. The Universal Strap should then be **fed through the space on the car seat where the seat belt would be fed through.** Note: the position of the cleats on the universal strap should be positioned on the **outer most Grommet Hole on side of the Strap and the middle Grommet hole on the alternate Side.**



- 2) The Travelmate should now be aligned with the bottom of the car seat. The Tabs on the bottom of the Travelmate should rest underneath the base of the car seat.



3) Insert the two Thumbscrews into the Travelmate Plate and screw them into the Cleats. The Thumbscrews should be inserted into the 2nd hole from the top.



4) Simply tighten the Thumbscrews and your Travelmate is ready for use.

