

Here are some helpful Hints for attaching the Travelmate to your First Years True Fit Convertible car seat:

You will need the following components:

- A) Universal Strap with cleats and O-rings
- B) 2 Thumbscrews
- C) Your assembled Travelmate Plate



- 1) Start By laying your car seat face down on the floor. **The True Fit has a recline feature however we recommend the seat to remain in the forward position for proper installation.** Feed the Universal Strap through the space in the back of the car seat where the seat belt is normally fed. **Please note the position of the cleats on the strap should be on the inside grommet hole on side of the strap with 2 holes and the 3rd grommet hole in from the opposite side. (3 holes in counting from the outside of the strap) ***



- 2) Now lay the Travelmate down onto the seat positioning the support tabs underneath the bottom of the cars seat as shown. Please note that the Support tabs will rest just under the bottom of the seat as there are no “ribs” on the True Fit.



- 3) Insert the two thumbscrews into the 2nd hole down from the top of the 5 allotted holes running down each side of the Travelmate. Then simply screw the thumbscrews into the cleats and tighten fully. It may seem as though the Strap is short, but by tightening the thumbscrews the strap will reach sufficiently.



- 4) You are now ready to use your Go-Go Babyz Travelmate!

