

Here are some helpful tips and images for attaching the gogo Kidz Travelmate to the Graco Nautilus

You will need the following components:

- Assembled Travelmate Plate
- Universal Strap, with Cleats attached by the O-rings
- 2 Thumbscrews.



- 1) Lay your car seat face down on the floor. Feed the Universal Strap through the space in the back of the car seat where the seat belt is normally fed. **Please note the position of the cleats on the strap should be on the inside grommet on the side with 2 holes and the outside grommet on the side with 4 holes.**



- 2) Now lay the Travelmate down onto the seat positioning the support tabs underneath the bottom of the ribs as shown. **The Travelmate support tabs will not physically hook under the metal rods of the Nautilus but the placement of the plate should be as shown.**



- 3) Insert the two thumbscrews into the 2nd hole from the bottom of the 5 allotted holes running down each side of the Travelmate. Then simply screw the thumbscrews into the cleats and tighten fully. *** It is important that the universal strap be positioned on the top portion of the belt space as shown.***



- 4) You are now ready to use your Go-Go Babyz Travelmate!



