

Here are some helpful tips and images for attaching the  
gogo Kidz Travelmate to the Maxi Cosi Priori

You will need the following  
components:

- Assembled Travelmate Plate
- Universal Strap, with Cleats attached  
by the  
O-rings
- 2 Thumbscrews



- 1) Lay **the car seat face down** on the floor and **thread the universal strap** through the space in the back of the Priori where the car seat belt would normally be fed.



- 2) Note from the picture above and below that the **cleat** is on the **outer most grommet hole of the strap**, on the **alternate side it is on the 2<sup>nd</sup> grommet hole** and both cleats are attached with the O-ring.



- 3) Next you will need to properly align the Travelmate plate onto the back of the car seat. Unlike most car seats, you will need to **place the support Tabs of the Travelmate under the base of the car seat.**



- 4) The **Thumbscrews** will then need to be inserted into the Travelmate plate into the **second hole from the top** of the five holes that run down the side of the Travelmate plate and **inserted into the cleats.**



- 5) Then simply tighten the Thumbscrews on both sides and your Travelmate is ready for use.

