

Here are some helpful Hints for attaching the Travelmate to your Recaro Como or Signo Car Seat.

You will need the following components:

- A) The Long Evenflo Strap with cleats and O-rings
- B) 2 Thumbscrews
- C) Your assembled Travelmate Plate



- 1) Start By laying your car seat face down on the floor. Feed the Long Strap through the space in the back of the car seat where the seat belt is normally fed. Please note the strap rests behind the metal bracing of the seat as seen in the picture. The position of the cleats on the strap should be on the outside grommet on the side with 2 holes (**outermost grommet hole**) and the 3rd grommet on the side with 3 holes. (**innermost grommet hole**)



- 2) Now lay the Travelmate down onto the seat positioning the support tabs underneath the bottom of the ribs as shown. The Travelmate plate should be centered on the car seat.



- 3) Insert the two thumbscrews into the 4th hole from the top of the 6 allotted holes running down each side of the Travelmate. Then simply screw the thumbscrews into the cleats and tighten fully.



- 4) You are now ready to use your Go-Go Babyz Travelmate!

