

gogo Kidz® Travelmate Model: QRKIDZ

Strap Use & Adjustments



OR STRAP Guide

gogo Kidz® Travelmate Model: QRKIDZ Strap Use & Adjustments

This guide will assist in the basic use of the new gogo Kidz Travelmate model# QRKIDZ. In this guide we will review the use of the Leather QRKIDZ strap, adjusting the strap position and adjusting the strap length. Once the strap is installed in the correct position for your Travelmate compatible seat, it will not need to be removed from the Travelmate plate for use with the same car seat.

For attaching the gogo Kidz Travelmate to your compatible car seat please refer to the manual or our Attaching guides. The attaching guides can be found on our website, www.gogobabyz.com. Simply Select the customer service section, then gogo kidz Travelmate support from the left hand menu.

BASIC USE OF THE QRKIDZ STRAP

The QRKIDZ strap utilizes a ratchet buckle and ladder strap.



To attach the Travelmate simply feed the strap into the lower portion of the buckle (image 2) beneath the “Teeth” of the buckle (image 3). Then simply pull up on the silver ratchet buckle lever a few times to close the slack in the strap (tighten the strap).



To release the strap from the buckle, simply pull the **Black Lever** on the buckle (image 4) in the opposite direction the silver buckle was pulled. This will allow you to remove the ladder strap from the buckle. **NOTE:** if the strap is over tightened there will be added tension on the strap, making releasing the buckle more difficult. You may need to pull firmer on the black release lever



ADJUSTING THE POSITION OF THE STRAP ON THE GOGO KIDZ TRAVELMATE PLATE:

Depending on your seat type, the strap may need to be raised or lowered from its original position on the plate. Go-Go Babyz has assembled the strap in the most common position for car seats.

The QRKIDZ strap is comprised of two parts, a ratchet buckle and a ladder strap. Both of these components are attached to the Travelmate in one of the six holes found running down each side of the gogo Kidz Travelmate Plate. The Components are secured with binding posts, which will need to be unscrewed using a Phillips head tool. Once the binding posts have been removed, simply select the hole which best mimics the same path as your car seat belt would be when installed in the car. You want the strap to be as level as possible to obtain the most secure attachment. Once the correct hole is found, simply reinsert the binding post through the attachment component (either the ratchet buckle or ladder strap) and secure from both sides of the plate. Make sure that you have installed the components in the same hole position on each side of the plate, IE 3rd hole on each side.



ADJUSTING THE LENGTH OF THE QRKIDZ STRAP:

The strap length is secured through a set of binding posts similar to how the buckle and ladder strap are attached to the Travelmate plate. To lengthen or shorten the strap, undo and remove the binding posts along the strap. Then either feed or pull the strap through the buckle to shorten or lengthen the strap. Make sure to realign the holes on the strap while folding the strap over on itself to reinsert the binding posts through both sides to prevent slack or flapping. Each binding post will reinsert through the two sides of the strap and into itself using a Philips head tool.

